



Инструкция по обновлению прошивки для AMT EgoGig EG-4

1. Подключите EG-4 с помощью USB кабеля к компьютеру.
2. Подключите блок питания к EG-4.
3. Скопируйте в корневую папку дискового накопителя файл прошивки для EG-4 – **“firmware”**.
4. Безопасно отключите устройство (USB-Drive) и отсоедините USB кабель.
5. Обновление программы будет выполнено в течении нескольких секунд: следите за обновлением прошивки на дисплее, дождитесь окончания этого процесса.

ВНИМАНИЕ! НЕ ОТКЛЮЧАЙТЕ питание EG-4 до завершения процесса обновления прошивки прибора!!!

6. При появлении на дисплее прибора надписи **“Reset device power”**, отключите питание от EG-4.
7. Вновь подключите питание к девайсу EG-4: через несколько секунд прибор войдет в режим полной готовности к работе.



Update instruction for AMT EgoGig EG-4

1. Connect your EG-4 device to computer an USB cable.
2. Power on your EG-4 device by power supply.
3. Copy in the USB drive root folder the file – **“firmware”** (it is in the unzipped folder).
4. Safely unmount USB-drive and disconnect the USB cable.
5. The firmware update will be completed in some seconds, take a look to your EG-4 display.

ATTENTION! DO NOT turn off the CP-100 power until the process is complete!!!

6. When the message **“Reset device power”** appears on the display, disconnect the power supply from your EG-4.
7. Power on your EG-4 device by power supply again. After a few seconds, the device will be ready to work.