




Инструкция по обновлению прошивки для AMT Pangaea: VC-16 / CP-16 / CP-16A-6F22

- **1. НЕ ПОДАВАЯ ЭЛЕКТРОПИТАНИЯ**, подключите устройство AMT к компьютеру:
- **VC-16** - с помощью mini USB кабеля;
 - **CP-16A-6F22** - с помощью micro USB кабеля;
 - **модуль CP-16** - через отладочную плату AMT Pangaea CP-16M-EB (Evaluation Board) с помощью USB B кабеля (или иным способом).

При этом устройство определяется компьютером как обычная флешка (**USB-Drive накопитель**).

- **2.** На странице <http://media.amt-sales.com/firmware-for-cp-16/> найдите и скачайте файл архива в формате .zip с необходимой версией прошивки:



- **3.** Разархивируйте файл в любую папку на вашем компьютере.
- **4.** Скопируйте в корневую папку **USB-Drive накопителя** файл прошивки "**firmware**" из только что распакованного архива.
- **5.** **Безопасно отключите USB-Drive** и отсоедините USB кабель.
- **6.** **Теперь запитайте прибор AMT:**
- Подключите адаптер питания к устройству **VC-16**;
 - Подайте питание на модуль **CP-16 / CP-16A-6F22**.
- **7.** Обновление программы будет выполнено автоматически в течении нескольких секунд. На всякий случай, отведите для этого процесса порядка 30 секунд (засеките время).

ВНИМАНИЕ! **НЕ ОТКЛЮЧАЙТЕ** питание прибора AMT до завершения процесса обновления прошивки!!!

- **8.** Теперь устройство полностью готово к работе.



Update instruction for AMT Pangaea: VC-16 / CP-16 / CP-16A-6F22

- **1.** Connect the AMT device to your computer **WITHOUT POWERING IT**:
- **VC-16** - using USB mini cable;
 - **CP-16A-6F22** - using USB micro cable;
 - **модуль CP-16** - via AMT Pangaea CP-16M-EB (Evaluation Board) using USB B cable (or any other way).

The device is determined by the computer as a regular **USB-Drive**.

- **2.** From the page <http://media.amt-sales.com/firmware-for-cp-16/> - download the archive file .zip with the required firmware version:



- **3.** Unzip the file to any folder of your computer.
- **4.** Copy the file "**firmware**" (which is in the unzipped folder) to the root folder of the **USB-drive**.
- **5.** **Safely unmount USB-drive** and disconnect the USB cable.
- **6.** Now **power on** the AMT device:
- Connect the power adapter to the **VC-16**;
 - Power the **CP-16 module / CP-16A-6F22**.
- **7.** The firmware update will be completed in some seconds automatically. Just in case, set aside about 30 seconds for this process.

ATTENTION! **DO NOT** power off the **VC-16 / CP-16 / CP-16A-6F22** until the process is complete!!!

- **8.** The device is ready to use.